

## SINGLE-POINT ADJUSTMENT

### Standard Features:

- No wrenches required to make top shaft adjustments.
- Readout indicates actual top-to-bottom shaft displacement in inches.
- Readouts on both inboard and outboard stands.
- Screw jacks have anti-backlash gearing.
- Spring-loaded linkage coupling makes cocking or uncocking shaft easy (see below).
- Can be retrofitted to existing Yoder or non-Yoder mill stands.



You can learn more about Yoder here:



[formtekgroup.com/brands/yoder/equipment](http://formtekgroup.com/brands/yoder/equipment)

### Optional Features:

- Electronic counters with LCD readouts and re-settable displays for quick and easy setting of the tooling gaps.
- Spring-loaded top caps for tube mill breakdown stands.
- Special fittings available to accept powered wrenches for even faster adjusting.

